

# Quickstart Guide

## GASMAX II Gas Monitor with Remote Electrochemical (Toxic) Sensor

### INSTALLATION

**IMPORTANT - Before installing the GASMAX II, make sure no toxic or combustible gases are present. Declassify the area if necessary.**

Air movement by fans, wind, gas density, convection, emission sources and environmental variables should be taken into account when determining location. As with all sensors, the GASMAX II should be protected from falling or directed water, snow, shock, vibration and dirt.

Use installation practices approved for the appropriate area classification. When installed with #10-0247 Stainless Steel sensor head, the GASMAX II is certified for use in areas rated Class 1, Div 1, Groups B, C & D.

### WIRING

Remove the GASMAX II display assembly by unscrewing the explosion-proof cover, loosening the two thumbscrews and removing the electronics assembly. The display board is located on the back of the display assembly.

Connect the GASMAX and remote sensor as shown using the 25ft shielded cable supplied with the unit. NOTE: Do not substitute cable or add additional cable beyond 25 ft.


Re-attach the display assembly to the enclosure and replace the explosion proof cover.

### CALIBRATION

Apply power and allow the instrument to warm up for a minimum of three (3) hours.


Hold the magnetic wand next to the CAL button (lower left side of display) until the screen indicates CAL? Then hold the wand over the EDIT button to confirm calibration mode.

Follow the on-screen instructions to calibrate the unit. When calibration is complete, the GASMAX II will indicate CAL DELAY and then resume normal operation. For more information, please read the GASMAX Users Manual supplied with the unit.




AUTHORIZED DISTRIBUTOR - GasDetectorsUSA.com - Houston, Texas USA

## GASMAX II 4-20mA WIRING DIAGRAM



## GASMAX II MODBUS® INTERFACE WIRING DIAGRAM



## GASMAX II ISOLATED 4-20mA WIRING DIAGRAM

